




TECHNOCRATIC SERVICES

ISO 9001:2015 Certified Company

Manometer for differential pressure

Description	Image
<p>MANOMETER: Model; Tea-700 Manometer is composed of firm white moulded polystyrene shell, indicator tube, fluid casing pipe, moulded ABS adjusting knob, glass graduated tube with shock absorber and leakproof O-gasket ring. There are printed degree scale on aluminous panel. The differential pressure gauges are widely utilized for measuring pressure of fan and blowing machine, resistance of filter, wind speed, furnace pressure, differential pressure of pore plate, the pressure of drum water level, liquid amplifier and hydraulic pressure system.</p> <p>Pressure limits: -10 to 600 Pascl Type: Vertical scale Temperature limit: 60 °C Accuracy: ±3% FS Scale length: 21 cm Weight: 472 g</p> <p>Application: For the differential pressure of HVAC & clean room Make: Hong Kong</p>	

For: Technocratic Service

Erum Manzoor
0333-0297007

Head Office Karachi

- +92-21-35001798
- +92-333-0297007
- +92-321-2202241
- +92-300-3972448
- Plot No. 763, Future Colony Mor, Main Korangi Industrial Area Road, Karachi-75120

- www.technocratics.com.pk
- technocratics@gmail.com
- info@technocratics.com.pk

Branch Office Lahore

- 0333-0297007, 0335-4944616, 0321-2202241
- Plot # 42, Street # 2, Block-C, Asim Town, Harbanspura Underpass Near Ring Road, Lahore-Pakistan.