



TECHNOCRATIC SERVICES

ISO 9001:2015 Certified Company

Sterile area/Clean room Air born Particle control & Microbial contamination controlled Stainless Steel Fogger

Description	Image
<p>Technocratic is supplier of Stainless steel fogger to control the microbial contamination in sterile area area. Disinfection of Sterile or clean room Fogger used in wide range Fumigation applications Pest Control, Odor Neutralizing, Sanitizing, Disinfecting, Dust settling, Asbestos remediation, Removing Smoke, Mist Generation, Humidifying including Flood and Fire damage restoration, among other applications.</p> <p>The fogger can be used to spray both water or oil based solutions, so it can be used with water, sanitizing solutions or insecticides. For storing fogging liquids the fogger has got a 0.5 gallon (1.9L) large solution tank that attaches to the bottom of the fogger. The solution container can be easily detached from the fogger which allows for easy filling of fogging liquids as well as easy cleaning of the reservoir.</p> <p>Parameter:</p> <p>Item: Fogger Voltage: AC110V/AC220V Power: 1200W Tank Capacity: 5.5L Fog Particles: 0-20 microns Spray Distance: 6m-8m Power Line Length: about 3m Max. Spray Rate: 400ml/min Weight: 3.6kg Size: 26x22x42cm</p> <p>Features:</p> <ol style="list-style-type: none">1. Advanced corrosion-resistant.2. The main body of stainless steel material is strong and resistant to falling;3. Strong horsepower, high speed aerosol, good cooling system4. Large amplitude, fast diffusion, fine atomization and strong penetration. <p>Principle:</p> <p>ULV (Ultra low volume) fogger are generally used for fogging. By these fogger machines solution is sprayed in the sterile area in form of aerosol to control air born particles and microbial growth. The small particles of disinfectant solution suspend in the air for long time and kill all the air borne bacteria, fungus and their spores. This is also very effective way to control the contamination.</p> <p>Make: Taiwan</p>	

Head Office Karachi



+92-21-35001798



www.technocratics.com.pk

+92-333-0297007



technoratics@gmail.com



+92-321-2202241



info@technocratics.com.pk

+92-300-3972448



Plot No. 763, Future Colony Mor, Main Korangi Industrial Area Road, Karachi-75120

Branch Office Lahore



0333-0297007, 0335-4944616, 0321-2202241



Plot # 42, Street # 2, Block-C, Asim Town, Harbanspura Underpass Near Ring Road, Lahore-Pakistan.