



# TECHNOCRATICS (Pvt) Ltd.

ISO 9001:2015 Certified Company  
NTN # A351529 GST # 3277876261645



## Cardboard Burst Strength Tester

(Improve the QC Lab's Package Testing Quality)

Machine for tester of master carton or shipper

### Description:

This digital cardboard bursting strength tester is applied to test bursting strength for paperboard, corrugated board and other sheet material etc. Standard :ISO2759, GB/T1539 etc. This burst tester is fully automatic-type bursting strength tester, Just put into the testing material, the tester automatically detect, automatic testing, automatic hydraulic recoil and automatic computing, storage testing data and printing. It is an important tester for controlling quality of finished product and quality inspection

### Character:

1. You just operate the operation panel to complete the test process, very easy.
2. The LCD screen can real-time display the working pressure, peak value.
3. It can save 40 groups of test data, automatically calculate the average value, max. Value.
4. It is equipped with built-in printer, it can print the test result.
5. It is equipped with the emergency stop button, improves the security.

Sr. #	Technical Parameter:	
1	Unit	KPa, kgf/cm <sup>2</sup> , lb/in <sup>2</sup>
2	Measuring Range	250~5600kpa
3	Resolution	1kpa
4	Oil pressure speed	170±15ml/min
5	Specimen Clamping Force	>690kpa
6	Hydraulic oil	silicone
7	Indicating Method & Display	LCD
8	Material of the clamp	Ring Stainless Steel
9	Upper compression plate size Diameter	95mm, bore diameter
10	31.5mm Lower compression plate size Diameter	135mm, bore diameter
11	31.5mm Clamping method Pneumatic	
12	Dimension (L*W*H)	430*530*520mm
13	Weight	about 70 kg
14	Power	1- phase, AC220±10%, 50 Hz



# TECHNOCRATICS (Pvt) Ltd.

ISO 9001:2015 Certified Company  
NTN # A351529 GST # 3277876261645



Picture:

